


FusionTV Remote Control User Guide

Contact us at (563) 245-4000 or visit www.alpinecom.net for more information.



Note: Some button functionality (eg DVR) may not be available on specific models of STB and functionality also varies with the type of TV service you subscribed to.

FusionTV Whole-Home Cloud DVR User Guide

Contact us at (563) 245-4000 or visit www.alpinecom.net for more information.

RECORD A PROGRAM

Press the **GUIDE** button to view the program guide. Using the arrow keys, highlight the program you want to record and press the **RECORD** button. If you are already watching the program, simply press the **RECORD** button to begin recording.

STOP RECORDING

Press the **STOP** button and follow the on screen directions. If you started the recording using the Guide, the recording will stop when the program is finished.

WATCH A RECORDING

Press the **DVR** button to view your list of recorded programs. Use the arrow keys to select the recorded program you want to watch and press **PLAY** to start playing the recording.

DELETE A RECORDING

Press the **DVR** button. Use the arrow keys to select the recording you want to delete and follow the on screen directions.

WHOLE-HOME CLOUD DVR


service gives you the freedom to record the program you are watching as you are watching it, record up to 9 other programs while you watch another, or record an upcoming show you see in the program guide. You can also schedule a series recording so you can catch all episodes of your favorite program. Being software-based and hosted in the cloud, you can record all the shows you want, watch them at the times you want, and enjoy them from any connected television in the home.

\$9.95/month – 2 streams of recording and 250GB of storage

\$12.95/month – 4 streams of recording and 250GB of storage

\$19.95/month – 4 streams of recording and 500GB of storage

250GB of storage is equivalent to approximately 50 hours of HD programming.



REWIND
Rewind through parts of a recording. Press multiple times to rewind faster.

PLAY
Begin or resume watching a recording. Also display/remove the status bar.

SKIP BACK
Skip backwards 10 seconds while watching a recording.

STOP
Stop watching a recording or stop a recording that is in progress.

DVR
Press to see your list of recorded programs. Press it again to see what is scheduled to be recorded.

PAUSE
Pause the program you are currently watching. While paused, the Fast-Forward button will play the program frame by frame in slow motion.

FAST FORWARD
Fast forward through parts of a recording. Press multiple times to go forward faster.

SKIP FORWARD
Skip forward 30 seconds while watching a recording.

RECORD
Record a program.

ARROWS/BROWSE/SEARCH/OK
Press to navigate through the guides, menu options or to make selections.

GUIDE
Access the program Guide. Press a second time for alternate view.

NOTE: The DVR is not intended to be a long-term storage device. Keep in mind that once you reach your space limitation maximum, older shows will be deleted.